









1. put filler (12) on the battery. 2. put the battery water (11) on the filler, press hard. 3. after put all the watter into the battery, put the seal plate(13) on the battery. 4. connect the positive pole of scooter and battery, connect the cathode of scooter and battery, use bolt(8) washer(9) and nut(10) to fix well.